

# **Connectors Installation Guide**

# **Radiance Series LED Tape Connectors**

Radiance Single Color Part # R-24NBxx3.0
Radiance RGB Part # R-24RGB4.4

### RADIANCE SINGLE COLOR 2PIN LED TAPE: R-24NBxx3.0



R-T-TFWB2P - Radiance Tape-to-Tape Flex Wire Bridge
Use: Increase bending radius for corners or cut at wire for Tape to Wire.



R-T-T2P - Radiance Tape-to-Tape. Use: Join sections of Tape together.



HDT-W2P - High Density Tape-to-Wire. (Connector Only) Use: Insert wire for Tape to Wire connection. 18-22AWG.

#### **RADIANCE RGB 4PIN LED TAPE: R-24RGB4.4**



R-RGBT-TFWB4P - Radiance RGB Tape-to-Tape Flex Wire Bridge Use: Increase bending radius for corners or cut at wire for Tape to Wire.



R-RGB-T-T4P - Radiance RGB Tape-to-Tape. Use: Join sections of Tape together.



R-RGBT-WL4P - Tape-to-Wire Lead. Use: Tape to Power Wire.

### **INSTRUCTIONS**

Copper pad section only



1

Remove Adhesive



